# Page #1 Trap & Skeet ERAD

## PERSONAL ERAD PROGRAMING SHORCUTS

### ERAD BOOTING UP INSTRUCTIONS

| ERAD INSTRUCTION | SCREEN SAYS |
|---|---|
| [ | STD#BY |
| PRESS ENT | PIN#NB |
| PRESS ENT | UNLOCK |
| PRESS ENT | ###### |
| HOLD #9 TO FILL SCREEN WITH 9'S | 999999 |
| PRESS ENT | STD#BY |
| PRESS FLD | FIELD |
| ENTER YOUR FIELD # | YOUR FLD # |
| PRESS FLD | MIC #OF |
| PRESS 9 MIC ON / CALL FOR BIRD | GAME LAST SHOT |
| NOTE: PRESS 8 FOR MIC OFF ||
| ERAD SHUTS OFF IN 15 MIN WITH NO ACTIVITY ||

### ERAD SPECIAL INSTRUCTIONS

| | |
|---|---|
| TO MANUALLY PULL A TRAP TARGET | PUSH EITHER THE 1, 2, 3, 4, 5, OR 6 BUTTONS |
| TO SHOOT YOUR SKEET OPTION SHOT | PUSH THE OPT BUTTON |
| FOR THE NO BIRD SKEET OPTION | PUSH THE N/B BUTTON |
| TO MANUALLY MOVE FORWARD AND BACK THROUGH THE SKEET / TRAP POSITIONS / STATIONS | USE THE LEFT OF RIGHT ARROWS |
| AFTER SHOOTING LAST BIRD IN SKEET ERAD SCREEN WILL SAY END | PUSH FLD...THE FIELD # YOUR ON...AND FIELD ONCE AGAIN TO RESET GAME |

### TO CHANGE FIELD WITH ERAD BOOTED

| ERAD INSTRUCTION | SCREEN SAYS |
|---|---|
| PRESS FLD | FIELD |
| ENTER FIELD # | # YOU SELECTED |
| PRESS FLD | MIC #OF |
| PRESS 9 FOR MIC ON / NOW CALL FOR BIRD | LAST GAME SHOT |
| NOTE: PRESS 8 FOR MIC OFF ||

### TO CHANGE GAME AFTER ERAD BOOTED

| ERAD INSTRUCTION | SCREEN SAYS |
|---|---|
| PRESS SEL | MODE |
| PRESS 0 | GAME |
| PRESS ENT | GAME LAST SHOT |
| PUSH 0 TILL GAME OF CHOICE APPEARS | GAME OF CHOICE |
| PRESS ENT | STD#BY |
| PRESS FLD | FIELD |
| ENTER YOUR FIELD # | # YOU SELECTED |
| PRESS FLD | MIC#0F |
| PRESS 9 MIC FOR ON / NOW CALL FOR BIRD | GAME DISPLAYED |
| NOTE: PRESS 8 FOR MIC OFF ||

| Trap & Skeet ERAD BOOTING UP INSTRUCTIONS | |
| --- | --- |
| ERAD INSTRUCTION | SCREEN SAYS |
| PRESS A RED BUTTON ERAD BOOTS UP | STD#BY |
| PRESS ENT | PIN#NB |
| PRESS ENT | UNLOCK |
| PRESS ENT | ###### |
| HOLD #9 TO FILL SCREEN WITH 9'S | 999999 |
| PRESS ENT | STD#BY |
| PRESS FLD | FIELD |
| ENTER YOUR FIELD # | YOUR FLD # |
| PRESS FLD | MIC #OF |
| PRESS 9 MIC ON / CALL FOR BIRD | GAME LAST SHOT |
| NOTE: PRESS 8 FOR MIC OFF | |
| ERAD SHUTS OFF IN 15 MIN WITH NO ACTIVITY | |

| ERAD SPECIAL INSTRUCTIONS | |
| --- | --- |
| TO MANUALLY PULL A TRAP TARGET | PUSH EITHER THE 1, 2, 3, 4, 5, OR 6 BUTTONS |
| TO SHOOT YOUR SKEET OPTION SHOT | PUSH THE OPT BUTTON |
| FOR THE NO BIRD SKEET OPTION | PUSH THE N/B BUTTON |
| TO MANUALLY MOVE FORWARD AND BACK THROUGH THE SKEET / TRAP POSITIONS / STATIONS | USE THE LEFT OF RIGHT ARROWS |
| AFTER SHOOTING LAST BIRD IN SKEET ERAD SCREEN WILL SAY END | PUSH FLD…THE FIELD # YOUR ON…AND FIELD ONCE AGAIN TO RESET GAME |

| TO CHANGE FIELD WITH ERAD BOOTED | |
| --- | --- |
| ERAD INSTRUCTION | SCREEN SAYS |
| PRESS FLD | FIELD |
| ENTER FIELD # | # YOU SELECTED |
| PRESS FLD | MIC #OF |
| PRESS 9 FOR MIC ON / NOW CALL FOR BIRD | LAST GAME SHOT |
| NOTE: PRESS 8 FOR MIC OFF | |

| TO CHANGE GAME AFTER ERAD BOOTED | |
| --- | --- |
| ERAD INSTRUCTION | SCREEN SAYS |
| PRESS SEL | MODE |
| PRESS 0 | GAME |
| PRESS ENT | GAME LAST SHOT |
| PUSH 0 TILL GAME OF CHOICE APPEARS | GAME OF CHOICE |
| PRESS ENT | STD#BY |
| PRESS FLD | FIELD |
| ENTER YOUR FIELD # | # YOU SELECTED |
| PRESS FLD | MIC#0F |
| PRESS 9 MIC FOR ON / NOW CALL FOR BIRD | GAME DISPLAYED |
| NOTE: PRESS 8 FOR MIC OFF | |